



INSTALLATION INSTRUCTIONS

QUIET CEILING SQUARE TRIM BASED SERIES



Model: QCT901 with QCT1875

V90040F



Avoid Fire or Electric Shock

- *Installation Instructions for qualified electricians only.
- *Install per National Electrical Code and local regulations.
- *Read Installation Instructions completely before installation.
- *Failure to follow installation instructions may void warranties.



Fixture Mounting

BUTTERFLY MOUNTING:

1. Fixture comes equipped with Universal Butterfly Mounting Brackets and can take common 1 inch or 1 1/2 inch Black Iron or Galvanized Mounting Channels (Supplied by Others). See Fig. 1.
2. Position Fixture so the Mounting Channels lie on top of ceiling runners.
3. Fasten Mounting Channels securely to ceiling runners.
4. Secure Mounting Channels to Universal Butterfly Mounting Brackets with wire tie downs.

HANGER BAR MOUNTING:

1. Maximum Hanger Bar center span: 22-1/2 inches.
2. Spread Hanger Bars to full span of rafters.
3. Hammer Hangers to seal Hanger Bar Tabs in rafters. See Fig. 1.
4. Secure Hanger Bars using one (1) nail in Mounting Hole in each Flange.
5. Mudding Frame is sent unmounted from factory. Adjust Mudding Frame to applicable Ceiling thickness (1/2", 5/8", 3/4", 1") by setting in 30° increments until dashed Ceiling Thickness Indicator Mark shows through window in Mudding Frame. See Fig. 2.
6. Secure Mudding Frame using four (4) #6-32 x 1/2 inch Flathead Screws (for 1/2 inch, 5/8 inch and 3/4 inch Ceiling thickness) or four (4) #6-32 x 3/4 inch Flathead Screws (for 1 inch Ceiling thickness).

Fixture Mounting (Con't)

7. Adjust elevation of Fixture so Mudding Frame Edge will be flush with surface of finished Ceiling by loosening two (2) 1/4 inch Hex Bolts on both Universal Mounting Brackets. See Fig. 1.
8. Tighten two (2) 1/4 inch Hex Screws on both Universal Butterfly Mounting Brackets to secure Fixture. See Fig. 1.
9. Install Ceiling drywall up to Mudding Frame on Fixture so that the two (2) Mudding Frame Brackets on Fixture contact inside of Ceiling. See Fig. 3.
10. Realign Fixture to Ceiling with one (1) Flathead Screw through each of two (2) Mudding Frame Brackets. See Fig. 3.
11. Apply Drywall Tape and Mudding Compound to Mudding Frame perimeter Mudding Frame, Flathead Screws, Fixture Gap and surrounding area. Feather out Mudding Compound from Mudding Frame opening to surrounding ceiling area to produce a smooth, flat finish. See Fig. 3.




Figure 1



INSTALLATION INSTRUCTIONS (CON'T) V90040F QUIET CEILING SQUARE TRIM BASED SERIES Model: QCT901 with QCT1875

Fixture Mounting (Con't)




Figure 2




Figure 3

Trim Installation

1. Connect Safety Cable attached to Banana Bracket on Trim Mechanism (See Fig. 1 & Fig. 5) to Fixture by Inserting Safety Cable through opening in Fixture and Inserting Snap Hook (See Fig. 5) on end of Safety Cable into Hole in Bracket attached to Middle of Fixture Housing Cover (See Fig. 1).
2. Install Trim Mechanism into Fixture by pressing firmly to seat Ball Detent Catches. See Fig. 3.

Lamp Installation

Lamp Bracket accommodates from one (1) to three (3) accessories.

1. Remove Trim Mechanism from Ceiling.
2. Slide out Lamp and/or Accessories from under Bracket Arm to remove. See Fig. 4.
3. Replace Lamp and/or Accessories as necessary.




Figure 4



INSTALLATION INSTRUCTIONS (CON'T) V90040F

QUIET CEILING SQUARE TRIM BASED SERIES

Model: QCT901 with QCT1875

Hot Aiming

*Hot Aim Lamp with power ON for precise aiming.

*45 Degree Angular adjustment can be achieved without removing Trim Mechanism.

1. With power ON and Trim Mechanism in place, Insert Phillips Head Screwdriver through Hole or Slot in Trim into Bearing Funnel. See Fig. 5.
2. To Rotate Lamp, Turn 45-90 Flathead Screw to desired position using Visual Angle Indicators on Rotational Adjustment Ring. See Fig. 6.




Figure 5

90° Rotational Lamp Adjustment

1. Remove Trim Mechanism from Fixture.
2. Loosen Lock Knob.
3. Rotate Rotational Adjustment Ring until Lamp is in desired position using Angle Indicators for reference.
4. Tighten Lock Knob.
5. Replace Trim Mechanism into Fixture.




Figure 6